





**SR 031
CONSOLE**

NET	1	1
SCL	1	1
SDA	2	2
MUTE	3	3
STB_P	4	4
DT R	5	5
DT L	6	6
SW_PW	7	7
GND	8	8
+5V	9	9
	10	10
CTRL B	11	11
CTRLA	12	12
LIGHT	13	13